



Model ADRM13 Parts Lisat

Item#	Part#	Description	Q'ty
001	SE00001126	TOP PANEL	1
002	SE00001127	TAPPING SCREW 3X12(ZK)	6
003	SE00001128	TOP COVER	1
004	SE00001129	O RING D37.8 W2	1
005	SE00001130	FLASH LIGHT LENS	1
006	SE00001131	LED LENS	1
008	SE00001127	TAPPING SCREW 3X12(ZK)	4
009	SE00001134	LED HOLDER+PCB F ASS'Y (MR054)	1
	D10	INC. 10	
010	SE00001136	RUBBER PAD A	2
011	SE00001137	HANDLE	1
013	SE00001138	WATERPROOF PLUG A	1
014	SE00001139	TOP CABINET ASS'Y	1
015	SE00001140	HEX SOCKET HEAD BOLT M4X16	4
016	SE00001141	FIXER BAR	1
017	SE00001216	HEX SOCKET HEAD BOLT M4X13	1
018	SE00001127	TAPPING SCREW 3X12(ZK)	4
019	SE00001144	SPEAKER	1
020	SE00001146	PACKING	1
021	SE00001147	ANT WIRE	2
022	SE00001148	SCREW STB 3X12(MC)	4
023	SE00001149	WATERPROOF PLUG B	1
024	SE00001150	LAMP COVER ASS'Y	1
025	SE00001141	FIXER BAR	1
026	SE00001216	HEX SOCKET HEAD BOLT M4X13	1
027	SE00001141	FIXER BAR	1
028	SE00001216	HEX SOCKET HEAD BOLT M4X13	1
029	SE00001141	FIXER BAR	1
030	SE00001216	HEX SOCKET HEAD BOLT M4X13	1
031	SE00001218	HEX SOCKET HEAD BOLT 3X12	4
032	SE00001152	PCB D+E LIGHT CTRL ASS'Y	1
033	SE00001127	TAPPING SCREW 3X12(ZK)	5
034	SE00001225	REAR BOTTOM CABINET ASS'Y(OLIVE)	1
	D10	INC. 35	
035	SE00001158	USB RUBBER COVER	1
036	SE00001159	PCB K ASS'Y	1
037	SE00001160	TAPPING SCREW 2X6	2
038	SE00001226	PCB H ASS'Y (USB JACK)	1
039	SE00001160	TAPPING SCREW 2X6	4
040	SE00001163	BOTTOM CABINET PACKING D1.5xL2	1
041	SE00001165	LXT TERMINAL(18V) ASS'Y	1
042	SE00001160	TAPPING SCREW 2X6	4
043	SE00001240	PCB A ASS'Y	1
044	SE00001160	TAPPING SCREW 2X6	4
045	SE00001233	PCB C ASS'Y(FCC)	1
047	SE00001238	FRONT BOTTOM CABINET ASS'Y(OLIVE)	1
A01	SE00001178	STRAP WITH HOOK	1