



Model GBP01Z Parts List

Item#	Part#	Description	Q'ty
001	273030-6	GRIP	1
002	922453-2	HEX.SOCKET HEAD BOLT M8X30	2
012	183V79-9	HANDLE SET	1
	C10 8012U4-2	XGT LOGO LABEL	1
	D10	INC. 18	
013	911243-8	PAN HEAD SCREW M5X25	2
014	620A64-0	DIAL CURCUIT	1
015	231433-0	COMPRESSION SPRING 4	1
016	412551-5	LOCK OFF BUTTON	1
017	651486-7	SWITCH C3JW-4B-R	1
018	183V79-9	HANDLE SET	1
	C10 8012U4-2	XGT LOGO LABEL	1
	D10	INC. 12	
019	265995-6	TAPPING SCREW 4X18	4
020	8116W2-6	GBP01 SERIAL NO. LABEL	1
021	632P49-4	TERMINAL UNIT	1
022	620J36-9	CONTROLLER	1
023	620549-0	LED CIRCUIT	1
024	183V14-7	MOTOR HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2
	D10	INC. 30	
026	629B03-3	STATOR	1
027	210017-7	BALL BEARING 607DDW	1
028	519736-5	ROTOR ASS'Y	1
	D10	INC. 27,29	
029	210141-6	BALL BEARING 6000DDW	1
030	183V14-7	MOTOR HOUSING SET	1
030	C10 263005-3	RUBBER PIN 6	2
030	D10	INC. 24	
031	265995-6	TAPPING SCREW 4X18	4
032	8116V6-1	GBP01 NAME PLATE	1
033	266056-5	TAPPING SCREW 5X45	4
034	141G83-4	REAR FRAME COMPLETE	1
034	C10 263005-3	RUBBER PIN 6	1
034	C20 424736-1	SPONGE	1
035	227930-2	SPIRAL BEVEL GEAR 11	1
036	211487-3	BALL BEARING 6202DDW	1
037	961055-9	RETAINING RING S-15	1
038	227934-4	HELICAL GEAR 61	1
039	210029-0	BALL BEARING 608ZZ	1
040	141H06-8	GEAR HOUSING COMPLETE	1
041	347940-4	STOPPER PLATE	1
042	922224-7	H.S.H.BOLT M5X16 WITH WG	2
043	210017-7	BALL BEARING 607DDW	1
044	227931-0	SPIRAL BEVEL GEAR 29	1
045	227932-8	SPUR GEAR 12	1
046	210017-7	BALL BEARING 607DDW	1
047	210029-0	BALL BEARING 608ZZ	1
048	961054-1	RETAINING RING S-14	1
049	227933-6	SPUR GEAR 39	1
050	327947-6	SPINDLE	1

051	211487-3	BALL BEARING 6202DDW	1
052	422845-0	GASKET	1
053	312C55-4	BEARING BOX	1
054	911243-8	PAN HEAD SCREW M5X25	5
055	256689-4	PIN 4	1
056	413D72-4	REAR WHEEL COVER	1
057	961017-7	STOP RING E-3	1
058	312C53-8	LOWER HOLDER	1
059	911138-5	P.H.SCREW M4X20 WITH WR	1
060	162B33-6	HOOK	1
061	911138-5	P.H.SCREW M4X20 WITH WR	1
062	210187-2	BALL BEARING 696ZZ	1
063	256033-5	PIN 6	1
064	210187-2	BALL BEARING 696ZZ	4
065	251337-0	+ PAN HEAD SCREW M5	2
068	267164-5	FLAT WASHER 15	1
069	421333-4	RUBBER TIRE	2
070	413D66-9	WHEEL B	1
071	253852-0	FLAT WASHER 8	2
072	265C56-0	H.S. HEAD BOLT M8X25	2
073	347942-0	SAW GUARD COVER	1
074	911128-8	P.H.SCREW M4X16 WITH WR	2
075	347941-2	SAW GUARD	1
076	911128-8	P.H.SCREW M4X16 WITH WR	2
077	327948-4	GUARD ROD 8	1
078	271470-2	LEVER 65	1
079	231955-0	RING SPRING 12	1
080	911138-5	P.H.SCREW M4X20 WITH WR	4
081	413D73-2	LEVER HOLDER	1
082	214408-4	PLANE BEARING 30	1
083	326351-6	LEVER SHAFT	1
084	234313-9	COMPRESSION SPRING 9	1
085	262130-7	URETHANE RING 4	1
086	265382-9	HEX. SOCKET HEAD BOLT M5X20	1
087	262130-7	URETHANE RING 4	1
088	266056-5	TAPPING SCREW 5X45	4
089	961017-7	STOP RING E-3	1
090	141G86-8	FRONT FRAME COMPLETE	1
	C10 263002-9	RUBBER PIN 4	1
	C20 263005-3	RUBBER PIN 6	1
091	162B48-3	SLIDE PLATE	1
092	268241-6	PIN 6	1
093	911138-5	P.H.SCREW M4X20 WITH WR	2
095	212199-1	NEEDLE BEARING 510	1
096	267010-2	FLAT WASHER 5	2
097	256155-1	PIN 5	1
098	911138-5	P.H.SCREW M4X20 WITH WR	1
099	312C54-6	UPPER HOLDER	1
100	911138-5	P.H.SCREW M4X20 WITH WR	1
101	256033-5	PIN 6	1
102	210187-2	BALL BEARING 696ZZ	1
103	210187-2	BALL BEARING 696ZZ	4
104	251337-0	+ PAN HEAD SCREW M5	2
107	162B33-6	HOOK	1
108	911138-5	P.H.SCREW M4X20 WITH WR	1
109	267164-5	FLAT WASHER 15	1

111	141G78-7	WHEEL COMPLETE A	1
114	256689-4	PIN 4	1
115	413D71-6	FRONT WHEEL COVER	1
116	911223-4	PAN HEAD SCREW M5X16	2
117	122B60-5	HOOK ASSEMBLY	1
118	263027-3	RUBBER PIN 4	1
A02	783202-0	HEX. WRENCH 4	1
A09	E-13225	BAND SAW BLADE/ 1140MM LENGTH	1