



Model HR1840 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	286037-3	CAP 34	1
002	961057-5	RETAINING RING S-17	1 PC.
003	253377-4	FLAT WASHER 17	1
004	457214-6	CHUCK COVER	1
005	257416-2	RING 21	1
006	216022-2	STEEL BALL 7.0	2 PC.
007	346177-0	GUIDE WASHER	1 PC.
008	232347-6	CONICAL COMP. SPRING 21-29	1
009	921923-8	HEX. BOLT M8X120	1 PC.
010	417911-6	GRIP BASE	1 PC.
011	266053-1	TAPPING SCREW 4X35	4 PC.
012	144272-8	GEAR HOUSING COMPLETE	1
	C10 213636-8	OIL SEAL 25	1 PC.
	C20 211375-4	BALL BEARING 6805LLB	1 PC.
013	213278-8	O RING 17	1 PC.
014	161568-2	LOCK BUTTON COMPLETE	1
015	232344-2	COMPRESSION SPRING 3	1
016	161569-0	CHANGE LEVER COMPLETE	1
017	158057-6	GRIP 36 COMPLETE	1 PC.
	C10 931402-8	HEX. NUT M8	1 PC.
018	457356-6	PLATE	1
019	853K43-5	HR1840 SERIAL NO. LABEL	1
020	961135-1	RETAINING(EXT) WR-25	1 PC.
021	267304-5	FLAT WASHER 25	1 PC.
022	232360-4	COMPRESSION SPRING 25	1
023	221494-8	SPUR GEAR 44	1
024	327039-1	DRIVING FLANGE	1
025	216019-1	STEEL BALL 3	3 PC.
026	326886-7	TOOL HOLDER	1
027	326887-5	IMPACT BOLT	1
028	213117-2	O RING 11	1 PC.
029	253380-5	FLAT WASHER 13	1
030	326888-3	RING 10	1
031	232357-3	COMPRESSION SPRING 10A	1
032	327038-3	CUP SLEEVE	1
033	233942-5	RING SPRING 22	1 PC.
034	267175-0	FLAT WASHER 24	1 PC.
035	345681-6	JOINT PLATE	1 PC.
036	347128-6	CHANGE PLATE	1
037	233458-0	COMPRESSION SPRING 32	1 PC.
038	326889-1	STRIKER	1
039	213832-8	O-RING 13	1
040	326890-6	PISTON CYLINDER	1
041	347127-8	GUIDE PLATE	1
042	324612-8	PISTON JOINT	1 PC.
043	232361-2	CONICAL COMP. SPRING 6-13	1
044	347130-9	SPRING GUIDE	1
045	211016-2	BALL BEARING 626LLB	1 PC.
046	221495-6	SPUR GEAR 12	1

047	326892-2	CAM SHAFT	1
048	326891-4	CLUCTH CAM	1
049	219029-7	SWASH BEARING 9	1
050	253383-9	FLAT WASHER 9	1
054	221496-4	HELICAL GEAR 23	1
055	211016-2	BALL BEARING 626LLB	1 PC.
057	213833-6	O-RING 60	1
058	144270-2	INNER HOUSING COMPLETE	1
059	213118-0	O RING 12	1 PC.
060	326893-0	RING 9	1
061	210162-8	BALL BEARING 609LLU	1
062	267231-6	FLAT WASHER 9	1 PC.
063	513987-2	ARMATURE ASS'Y 115V	1
	D10	INC. 59-62,64,65	
064	681670-0	INSULATION WASHER	1 PC.
065	210023-2	BALL BEARING 627DDW	1 PC.
066	267804-5	WAVE WASHER 15	1 PC.
067	457351-6	BUFFLE PLATE B	1
068	266069-6	TAPPING SCREW 4X45	2 PC.
069	633992-4	FIELD	1
074	144681-1	MOTER HOUSING B COMPLETE	1
	C10	813A71-2	CAUTION LABEL
077	CB458	CARBON BRUSH CB-458 (195025-8)	1 SET
078	632K41-0	BRUSH HOLDER UNIT	1
080	266326-2	TAPPING SCREW 4X18	3 PC.
081	457354-0	HANDLE COVER	1
082	266385-6	TAPPING SCREW 4X14	1 PC.
083	687681-3	STRAIN RELIEF	1 PC.
084	682559-5	CORD GUARD 8	1 PC.
085	664064-4	POWER SUPPLY CORD #18-2-4.0	1 PC.
086	651087-1	SWITCH	1
087	853K39-6	HR1840 NAME PLATE	1
088	813E00-9	CLEAR LABEL	1
A01	415486-9	DEPTH GAUGE	1 PC.
A02	821706-5	PLASTIC CARRYING CASE	1
	C10	162315-4	LATCH
	C20	324679-6	SHAFT
	C30	457340-1	HANDLE