



Model XRM10 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	TC00000001	FRONT BAR	2 PC.
002	TC00000002	VOLUME KNOB	1 PC.
003	TC00000003	USB COVER HOLDER	1 PC.
004	TC00000004	USB COVER	1 PC.
005	TC00000005	SCREW M6X45	4 PC.
006	TC00000006	FRONT CABINET BLUE	1 PC.
007	TC00000162	FRONT INNER CABINET ASSY	1 PC.
	D10	INC. 15-20	
009	TC00000009	SCREW M4X15	4 PC.
010	TC00000011	SCREW M3X8	1 PC.
011	TC00000012	VOLUME HOLDER COVER	1 PC.
012	TC00000011	SCREW M3X8	2 PC.
013	TC00000010	WIRE CLAMP	1 PC.
014	TC00000011	SCREW M3X8	4 PC.
015	TC00000013	MIDDLE KEY	1 PC.
016	TC00000014	MIDDLE KEY HOLDER	1 PC.
017	TC00000016	TOP KEY	1 PC.
018	TC00000017	TOP KEY HOLDER	1 PC.
019	TC00000015	SCREW M1.7X5	4 PC.
020	TC00000015	SCREW M1.7X5	5 PC.
021	TC00000019	COVER PCB	2 PC.
022	TC00000011	SCREW M3X8	4 PC.
023	TC00000020	PCBA-DISPLAY	1 PC.
024	TC00000178	FLAT CABLE	1 PC.
025	TC00000011	SCREW M3X8	10 PC.
026	TC00000163	PCBA-USB1 ASSY	1 PC.
027	TC00000021	PCBA-MAIN A	1 PC.
028	TC00000027	SHIELD	1 PC.
029	TC00000026	SCREW M3X8	2 PC.
030	TC00000011	SCREW M3X8	3 PC.
031	TC00000026	SCREW M3X8	2 PC.
032	TC00000029	PCBA-USB2	1 PC.
033	TC00000011	SCREW M3X8	2 PC.
034	TC00000030	PCBA CHARGING	1 PC.
035	TC00000011	SCREW M3X8	2 PC.
036	TC00000031	PCBA-CXT BATTERY	1 PC.
037	TC00000032	SCREW M2.6X6	2 PC.
038	TC00000011	SCREW M3X8	2 PC.
039	TC00000033	PCBA-SWITCH	1 PC.
040	TC00000011	SCREW M3X8	2 PC.
041	TC00000034	LXT TERMINAL HOLDER BLUE	1 PC.
042	TC00000011	SCREW M3X8	2 PC.
043	TC00000036	PCBA-LXT BATTERY	1 PC.
044	TC00000010	WIRE CLAMP	2 PC.
045	TC00000037	CXT TERMINAL	1 PC.
046	TC00000038	BAT SWITCH BUTTON BLUE	2 PC.
047	TC00000040	LXT SPRING	4 PC.
048	TC00000041	LXT TERMINAL	1 PC.
049	TC00000042	FRONT INNER CABINET RUBBER	1 PC.

050	TC00000045	SPEAKER BRACKET	1 PC.
051	TC00000032	SCREW M2.6X6	1 PC.
052	TC00000186	LEAD UNIT	1 PC.
053	TC00000047	SPEAKER RUBBER	1 PC.
054	TC00000048	SPEAKER L	1 PC.
055	TC00000049	SPK COVER	1 PC.
056	TC00000050	SCREW M6X14	4 PC.
057	TC00000051	RUBBER RING	4 PC.
058	TC00000052	SCREW M3X10	1 PC.
059	TC00000199	ANTENNA LEAD UNIT	1
060	TC00000053	FM ANTENNA	1 PC.
061	TC00000054	RUBBER RING	1 PC.
062	TC00000032	SCREW M2.6X6	1 PC.
063	TC00000186	LEAD UNIT	1 PC.
064	TC00000055	PCBA-DC JACK	1 PC.
065	TC00000015	SCREW M1.7X5	2 PC.
066	TC00000056	DC JACK HOLDER BLUE	1 PC.
067	TC00000058	BACK CABINET SHAFT	1 PC.
068	TC00000059	DC JACK COVER	1 PC.
069	TC00000060	SCREW M3X14	1 PC.
070	TC00000045	SPEAKER BRACKET	1 PC.
071	TC00000047	SPEAKER RUBBER	1 PC.
072	TC00000174	SPEAKER R	1 PC.
073	TC00000049	SPK COVER	1 PC.
074	TC00000051	RUBBER RING	4 PC.
075	TC00000050	SCREW M6X14	4 PC.
076	TC00000061	BATTERY PLUS PLATE	1 PC.
077	TC00000062	BATTERY MINUS PLATE	1 PC.
078	TC00000063	BATTERY MINUS PLUS PLATE	1 PC.
079	TC00000064	BATTERY COVER BLUE	1 PC.
080	TC00000066	HEXA SOCKET SCREW T15 3X45	2 PC.
081	TC00000067	MIDDLE CABINET RUBBER	1 PC.
082	TC00000068	SCREW M6X19	2 PC.
083	TC00000069	COMPRESSION SPRING	4 PC.
084	TC00000070	STEEL BALL	4 PC.
085	TC00000071	HANDLE PLATE R	1 PC.
086	TC00000072	HANDLE PLATE L	1 PC.
087	TC00000073	HANDLE L BLUE	1 PC.
088	TC00000075	GRIP	1 PC.
089	TC00000076	HANDLE R BLUE	1 PC.
090	TC00000078	SCREW M6X20	2 PC.
091	TC00000026	SCREW M3X8	1 PC.
092	TC00000175	BATTERY RUBBER PAD	1 PC.
093	TC00000011	SCREW M3X8	4 PC.
094	TC00000080	BOTTLE OPENER BACK COVER BLU	1 PC.
095	TC00000082	RUBBER RING	1 PC.
096	TC00000085	BOTTLE OPENER	1 PC.
097	TC00000086	HOLDER	1 PC.
098	TC00000011	SCREW M3X8	2 PC.
099	TC00000087	PHONE POCKET BLUE	1 PC.
101	TC00000089	SCREW M3X8	1 PC.
102	TC00000090	RUBBER RING	1 PC.
103	TC00000011	SCREW M3X8	2 PC.
104	TC00000091	BACK CABINET BLUE	1 PC.
105	TC00000093	SHAFT SHORT	1 PC.
106	TC00000094	HINGE BLUE	1 PC.

107	TC00000096	SHAFT LONG	1 PC.
108	TC00000097	LATCH BLUE	1 PC.
109	TC00000099	HOOK	1 PC.
110	TC00000100	CABINET HOLDER L BLUE	1 PC.
111	TC00000068	SCREW M6X19	2 PC.
112	TC00000102	CABINET HOLDER R BLUE	1 PC.
113	TC00000104	CABINET HOLDER BLUE	1 PC.
114	TC00000068	SCREW M6X19	2 PC.
115	TC00000179	4P WIRE	1 PC.
116	TC00000180	8P WIRE	1 PC.
117	TC00000181	2P/4P WIRE ASSY	1 PC.
122	TC00000169	LEAD UNIT	1 PC.
126	TC00000164	CXT TERMINAL ASSY	1 PC.
	D10	INC 36,45,63	
127	TC00000165	LXT TERMINAL ASSY BLUE	1 PC.
	D10	INC. 41,43,47,48	
128	TC00000168	MIDDLE CABINET ASSY BLUE	1 PC.
	D10	INC. 76,77,122	
129	TC00000172	DC JACK ASSY BLUE	1 PC.
	D10	INC. 64-66	
130	TC00000176	BACK CABINET ASSY BLUE	1 PC.
	D10	INC. 101.102,104-109	
A01	TC00000133	AC ADAPTER A	1 PC.
A02	TC00000145	AC CORD D	1 PC.